

Instruction Manual





Press the **Reset** button until it is complete, the installation progress done.

Notes:


1. Operating voltage: AC100~240V, frequency 50/60HZ
2. Operating temperature: -10~40°C.
3. Before use, please check whether all power lines are fully connected and firm.
4. Before use, please check the surrounding environment and ensure there are no obstructions above or below the table.
5. This product is not to be used by children. Adult supervision is required.
6. Do not use if any cables (electrical parts) are damaged.
7. The product is not suitable for mobile use. If you must move, please prevent it from being injured.
8. It is normal for a slight jitter when the table starts to rise and fall. This will not affect the service life.


888 Screen

 Up: Up button

 Down: Down button


 RST: Reset button

 Stand: Saving button 1

 Sit: Saving button 2





Reset Operation:

* When the table is installed for the first time or failure occurred during use, perform the following operations:





- ◆ Pull out the power cord and motor line, and then re-plug, to ensure that they are firm;
- ◆ Press and hold RST "  " for 3s until "---" is on the screen, release the button. The desktop automatically moves up and down to find the highest and lowest height. When this process stops, the reset operation is complete.

Do this first after the new table is installed.

Up and down button operation

- ◆ When the "  " button is pressed, the desktop runs up until reaching the highest height.
- ◆ When the "  " button is pressed, the desktop runs down until it reaches the lowest height.
- ◆ The display flashes when the "  " button is pressed for 3s, and when the button is released, it automatically reaches the highest point on the table, and can be stopped midway by any press.
- ◆ The display flashes when the "  " button is pressed for 3s, and when the button is released, it automatically reaches the lowest point on the table, and can be stopped midway by any press.

Location Store/Memory Location operation

- ◆ Press and hold "  " for 3s, the display flashes and the stand position is saved.
- ◆ Press and hold "  " for 3s, the display flashes and the sitting position is saved
- ◆ Station memory position running: press the "  " button, the desktop automatically run to the height of the memory position, and can be stopped midway by any press.
- ◆ Sitting memory position operation: press the "  " button, the desktop automatically runs to the height of the memory position, and can be stopped midway by any press.