


Assembly Instructions


Caution: You should read this carefully before you proceed

Leisure Chair



Part List


Label	Picture	Description	QTY
A	A line drawing of a circular seat component, showing a central indentation where a person would sit. It is enclosed within a dashed circle, indicating it is a separate part from the rest of the chair.	Seat	1

B		Frame	1
---	---	-------	---

Hardware

Label	Picture	Description	QTY
①		Bolt(M6x25mm)	5
②		Spring Washer	5
③		Washer	5
④		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:	
----------------------------	--



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-




Assembly Steps

Overview




This Leisure Chair has multiple parts and may require up to 20 minutes to assemble. To give you an overview of the Leisure Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Open the carton and place all the parts on a clean, non-marring surface.

Step 2



Place the Seat(A) facedown, on a clean, non-marring surface.

Attach the Frame(B) to the Seat(A) with the Allen Wrench(④), using Bolts(①), Spring Washers(②) and Washers(③) as shown above.



Tighten all Bolts fully in a sequential manner.

DO NOT fully tighten a Bolt in one go and then move on to the next.

Rather, In a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured.

This methodology will ensure maximum evenness once all Bolts are fully tightened.

Step 3



Adjust Pre-installed Levelers height to achieve balance

"Stand the Dining Chair up.

Adjust the Pre-installed Levelers at the bottom of the Lower Leg Frame(B), and Upper Leg Frame(C) until the Chair is level with the ground."

Step 3



Turn the Leisure chair rightside up. It is now ready for use.

This Leisure Chair can only be used on a flat, level surface.

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.