



# ASSEMBLY INSTRUCTION




## PARTS AND HARDWARE




## ASSEMBLY INSTRUCTIONS

Step 1




Step 2




# OPERATING YOUR UNIT


## Step 3




## Step 4



## Step 5




## Step 6




# OPERATING YOUR UNIT


Step 7




Step 8



Step 9




Step 10




# OPERATING YOUR UNIT


Step 11




Step 12



Step 13




Step 14



# OPERATING YOUR UNIT

Step 15



Step 16

