



# ASSEMBLY INSTRUCTION

## ASTORIA




### ASSEMBLY INSTRUCTIONS




#### PARTS AND HARDWARE

Note: Individual parts are not shown to scale.



#### Step 1



# OPERATING YOUR UNIT







Step 2

Step 3

Step 4

Step 5

Step 6









Step 2

Step 3

Step 4


Step 5

Step 6




# OPERATING YOUR UNIT


Step 7




Step 8




Step 9




Step 10




Step 7



Step 8



Step 9



Step 10

