


Assembly Instructions



Important


Please read through instruction carefully
Before assembly and keep for future reference.

WARNING


Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.


Important Tips and Maintenance




1.
Keep children and animals away from working area as smaller parts may cause choking if swallowed.



2.
Never place liquids or anything damp upon furniture as it will mark. Ensure a coaster or running is beneath.




3.
Never use ammonia based cleaning products as it will damage the finish.




4.
To avoid fading, keep furniture out of direct sunlight.



5.
Use a soft cloth (dry cloth) when wiping or cleaning surfaces.



6.
Two person are required.




7.
Lay a soft matt down to protect the furniture piece before and during assembly.

Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the centre of the cam lock when the two panels are joined.











Cam lock should be inserted before quickfit.



Turn cam lock clockwise to tighten.


Hardware List

Please check you have all the fittings part or tools are listed in below.


A  6*35mm 12 PCS	B  15*12mm 12 PCS	C  Φ8*30mm 22 PCS
D  16 PCS	E  4mm 1 PC	F  Φ6*45mm 6 PCS
G  4 PCS	H  4 PCS	I  Φ3.5*14mm 56 PCS
J  4 PCS	K  4 PCS	L  Φ8*410mm 2 PCS
M  2 PCS	N  2 PCS	O  5mm 1 PC
4		

Component Panels &part List

Please check you have all the panels
are listed below.




STEP 1




A 12 PCS

K 4 PCS

I 8 PCS




STEP 2




B 8 PCS


C 8 PCS




STEP 3



B
4 PCS




STEP 4




D
4 PCS

E
1 PC

STEP 5



STEP 6




C
8 PCS

D
12 PCS

E
1 PC

STEP 7




C  4 PCS

F  6 PCS

E  1 PC

STEP 8




G  4 PCS



H  4 PCS

I  16 PCS


STEP 9



STEP 10



STEP 11



L
2 PCS


C
2 PCS

M
2 PCS

O
1 PC

N
2 PCS

STEP 12



Note:

Please lift up the furniture by two people when moving is needed.
Dragging may cause the legs failure.