5HK5035SWH

Wine Cooler



ASSEMBLY GUIDE

Thank you for shopping from us!

To ensure a smooth installation and optimal use of this product, please carefully read the precautions and detailed operation instructions in this manual. We hope you have a great experience!

This assembly guide includes the Part List, Installation Steps, and Warning Tips.

To ensure your package arrives safely and intact, this item will be shipped in two boxes. Please check your package upon receipt. If you have any questions or issues after receiving our product, please feel free to contact us. We will respond within 24 hours and provide you with a suitable solution.

INSTALLATION

Pre-installation Inspection



			
1 1 PC	2 1 PC	3 1 PC	4 2 PCS
			
5 1 PC	6 4 PCS	7 1 PC	8 1 PC
			
9 1 PC	10 1 PC	11 1 PC	12 1 PC
			
13 2 PCS	14 2 PCS	15 2 PCS	16 1 PC
			
17 1 PC	18 2 PCS	19 1 PC	

A  M6x35 x20+1	B Ø15x10 x20+1	C Ø6x30 x20+2	D  x4	E M4x12 x22+1
F M4x35 x14	G M3.5x14 x35+2	H x8	I x5	J x2
K  x2		M  x1	N x8	O  x2
P x2	Q  x1	R  x2	S  x4	T x3 SET
U M3x12 x8	V x12			

STEP1


A
A
A
G
G
G
A
A
G
G
A
A
A
2
T
T
T
L
2
A
A
G
A
G
R
A
G
A
A
G
R
1


A
M6x35
x14
Q
x1
G
M3.5x14
x8
T
x3
R
x2

STEP2


E
E
D
D
G
G
G
M
3
E
D
E
D


G
G
S
G
G
S
14
P
O


G
G
S
G
G
S
P
14
O


D
x4
E
M4x12
x20
M
x1
G
M3.5x14
x11
S
x4
P
x2
O
x2

STEP3


F
F
C
10
C
12
C
C
F
9
F


C
B
C
11
C
B
B
C
10
B
2
C
C
9
C
B
B
C
8
B


C
Ø6x30
X12
F
M4x35
x4
B
Ø15x10
x8

STEP4





STEP5







STEP6





STEP7


1
B
V
B
V
B
V
B
V
B
V
B
4
5
4


G
14
G
G
14
G


A
B
C
Cabinet
Door
To adjust the vertical height.
Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.
Cabinet
Door
To adjust depth.
Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".
Cab
Door
To adjust side ways.
Turning the screw "C" on BOTH hinges on each door.


V
x6
B
Ø15x10
x6
G
M3.5x14
x16

STEP8







STEP9


H
U
H
U
H
U
U
H
U
H
U
H
L
U
H


U
M3x12
x8
H
x8


F
J
K
E
F
J
K
E
J
x2
E
M4x12
x2
K
x2
F
M4x35
x2