


# Cobalt Assembly Instruction



| ①    | ②    | ③    | ④    | ⑤    | ⑥    | ⑦    | ⑧    |
|------|------|------|------|------|------|------|------|
|      |      |      |      |      |      |      |      |
| 2 PC | 2 PC | 2 PC | 2 PC | 2 PC | 2 PC | 1 PC | 2 PC |

