


# ASSEMBLY INSTRUCTION


5 of 3




## ASSEMBLY INSTRUCTIONS

### PARTS AND HARDWARE

Note: Individual parts are not shown to scale.




### Step 1



1 of 3

# OPERATING YOUR UNIT

## Step 2




Step 1


БАЗА И НАДВОДКА

ASSEMBLY INSTRUCTIONS


## Step 3



## Step 2



## Step 3



ИНСТРУКЦИЯ СБОРА