











# ASSEMBLY INSTRUCTION

SKU#124303744/124303743

## PARTS LIST

## HARDWARE LIST

	NO.	DESCRIPTION	SKETCH	Q'TY	NO.	DESCRIPTION	SKETCH	Q'TY
	A	Chair Body		1pc	1.	Bolt 2"		4+1pcs Extra
					2	Bolt 2.5"		4+1pcs Extra
	B	Front Leg		2pcs	3	Flat Washer		8+1pcs Extra
	C	Back Left Leg		1pc	4	Spring Washer		8+1pcs Extra
	D	Back Right Leg		1pc	5	Allen Key		1pc




### WARNING

- Read all instructions carefully and completely before assembly and use. Retain for future reference.
- Keep plastic bags and small parts away from children.
- DO NOT use power tools.
- DO NOT overtighten hardware.
- Periodically check hardware and re-tighten as necessary.
- DO NOT use product if any component becomes damaged.
- For residential(non-commercial)use only.
- Max Weight Limit=275lb.
- DO NOT stand on product. Use only for intended purpose.

### Step1:


Remove legs (B, C, D) from storage pouch underneath Chair Body(A). Insert legs into openings on underside of Chair Body(A) as shown on diagram below.





## Step2:

Attach Front Legs (B) to Chair Body (A) using Bolts (2), Spring Washers (4), and Flat Washers (3). Attach Rear Legs (C,D) to Chair Body (A) using Bolts (1), Spring Washers (4), and Flat Washers (3). Fully tighten using Allen Key (5).



Assembly is completed.

