




ASSEMBLY INSTRUCTIONS

STEP 1 : Remove HANDLE (2) using a Philips head screw driver as shown in illustration STEP - A. Re-install the HANDLE (2) as per diagram STEP - B. Repeat STEP - A STEP - B until HANDLE (2) are attached correctly.



MODEL : C6377A CHEST			
PART LIST			
NO	ITEM	QTY	
A		1 PC	
HARDWARE LIST			
NO	ITEM	QTY	
1	Truss Head Machine Screw m4x38mm Blk 	10 PCS	
2	HANDLE L150mmxW21.6mmxH28mm 	5 PCS	

COMPLETED ASSEMBLY

NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.