



Scan QR code for hardware instructions





Scan QR code for hardware instructions






 ${\it Scan QR code for hardware instructions}$ 





Scan QR code for LED operation  $\,$ 








## Hardware installation demonstration NOTE:Please make sure "A"hardware tightened and can't be pulled out!













Make sure the arrow on the screw align to the hole on the side.






Make sure the arrow on the screw align to the hole on the side.












Make sure the arrow on the screw align to the hole on the side.







## **LED Light**

If you can't let the lights work successfully, please check the following:

- 1. Please check the direction of the connect, try it in the opposite direction, according to the following picture.
- 2. Please check the remote control, it need you to tear down the plastic septum before use it.
- 3. Don't let the remote control too far from the receiver, make sure there is no obstruction between them.

