


# ASSEMBLY INSTRUCTIONS

DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS

MODEL : C6413A-Q94-XXXX  
C6413A-QTA-XXXX  
C6413A-QXJ-2DXX  
C6413A-WX9-XXXX

REVISION : A

| Component List                         |                              |     |
|----------------------------------------|------------------------------|-----|
| Headboard & Footboard                  |                              |     |
| No                                     | Descriptions                 | Qty |
| A                                      | Headboard Panel              | 1   |
| B                                      | Footboard Panel              | 1   |
| C                                      | Headboard Back Cover         | 1   |
| D                                      | Footboard Back Cover         | 1   |
| E                                      | Slat Cover                   | 1   |
| Side Rail                              |                              |     |
| No                                     | Descriptions                 | Qty |
| F                                      | Bed Rail                     | 2   |
| G                                      | Drawer Slat                  | 1   |
| H                                      | Drawer Slat Support          | 1   |
| I                                      | Drawer Slat Support Stopper  | 1   |
| J                                      | Bed Slat 3 Holes             | 3   |
| K                                      | Bed Slat 2 Holes             | 10  |
| L                                      | Bed Slat Support             | 3   |
| M                                      | Center Slat With 3 Holes     | 1   |
| Leg                                    |                              |     |
| No                                     | Descriptions                 | Qty |
| N                                      | Headboard Leg Left and Right | 2   |
| P                                      | Footboard Leg Left and Right | 2   |
| Drawer                                 |                              |     |
| No                                     | Descriptions                 | Qty |
| Q                                      | Drawer                       | 2   |
| Hardware List In Headboard & Footboard |                              |     |
| No                                     | Descriptions                 | Qty |
| 1                                      | JCBC Screw M6 x 35mm         | 12  |
| 2                                      | Spring Washer Ø1/4"          | 12  |
| 3                                      | Flat Washer Ø1/4" x 20mm     | 24  |
| 4                                      | L Key M4 x 100mm             | 1   |
| 5                                      | L Key M5                     | 1   |
| 6                                      | Wood Dowel 10mm x 30mm       | 8   |
| 7                                      | JCBC Screw M6 x 16mm         | 12  |
| 8                                      | CSK M4 x 16mm                | 5   |
| 9                                      | JCBC Screw M6 x 50mm         | 3   |




| Hardware List In Headboard & Footboard |                 |     |
|----------------------------------------|-----------------|-----|
| No                                     | Descriptions    | Qty |
| 10                                     | CSK M4 x 32mm   | 30  |
| 11                                     | L Key M4 x 65mm | 1   |

NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.

# ASSEMBLY INSTRUCTIONS

DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS

- STEP 1.1: Insert wood dowel (6) to the pre-drilled hole of headboard panel (A) / footboard panel (B).  
 STEP 1.2: Push the headboard leg (N) / footboard leg (P) to fit with the wood dowel (6) at the headboard panel (A) / footboard panel (B).  
 STEP 1.3: Attach the headboard leg (N) / footboard leg (P) by using JCBC Screw M6 x 35mm (1), springwasher (2) and flat washer (3) through the pre-drilled hole of headboard leg (N) / footboard leg (P) and tighten by using Allen key (4).  
 STEP 1.4: Repeat Step 1.1 to step 1.3 For the other side leg.  
 STEP 1.5: Attach the headboard back cover (C) on the back side of headboard panel (A), and attach the footboard back cover (D) on the back side of footboard panel (B).



NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.

# ASSEMBLY INSTRUCTIONS

DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS


STEP 2.1: Attach the bed rail (F) to headboard leg (N).

STEP 2.2: Tighten screw on headboard leg (N) by using L key M5 (5) & repeat the same step on footboard leg (P).

STEP 2.3: Attach the drawer slat (G) each to a drawer slat support (H) & fix with drawer slat support stopper (I).

STEP 2.4: Fix the drawer slat (G) to bed rail (F) with CSK M4 x 32mm (10).

STEP 2.5: Move 'T' runner at footboard panel (B) to drawer slat (G).



NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.


# ASSEMBLY INSTRUCTIONS

DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS


STEP 3.1: Insert drawer (Q) to footboard (B) until completely closed.

STEP 3.2: Tighten "T" runner at footboard (B) to drawer slat (G) with CSK M4 x 16mm (8).



STEP 3.3: If drawer (Q) does not close properly, adjust the adjuster at the bottom of drawer slat support (H) up or down until the drawer (Q) closes tightly.






STEP 3.1



STEP 3.2



STEP 3.3




NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.

# ASSEMBLY INSTRUCTIONS


DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS

STEP 4.1: Attach the center slat (M), bed slat (J) to bed slat support (L). Tighten with JCBC M6 x 50mm (9) by using L key M4 (11).

STEP 4.2: Attach bed slat (J) & bed slat (K) and tighten to bed rail (F) with CSK M4 x 32mm (10).



## STEP 4.1




## STEP 4.2

NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.


# ASSEMBLY INSTRUCTIONS

DESCRIPTION : QUEEN STORAGE HEADBOARD & FOOTBOARD  
SIDERAIL / FOOTBOARD DRAWERS

- STEP 5.1: Insert the tip of slat cover (E) on the back of the footboard (B) until closely.  
STEP 5.2: Use CSK M4 x 16mm (8) to fasten the slat cover (E) on the bed slat (K).



STEP 5.1



STEP 5.2

NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE.  
CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.