

How to use Filler Wax



Step 1: Using a spatula or spoon, apply a generous amount of the filler wax directly on to any crack or gaps you wish to fill.

This Filler Wax is designed to be thick and retains a solid form in room temperature.






Step 2: To help the wax goes into the gap you wish to fill, we suggest using your fingers to press the wax into the space to ensure it is filled tight.

Don't worry if you have excess wax on the surface, this can be wiped off.



Step 3: Using a clean cloth or a durable paper towel, wipe off any excess wax on the surface.

After all excess has been removed from the surface, allow the wax to dry over night. If enough wax is used to fill the gap, there should be little to no shrinkage as it dries.



If Required:

You may wish to repeat Steps 1 to 3, if your are filling a large gap. Each attempt may help reduce the size of the gap, as you build a new layer of filler wax over the previous layer after it has dried completely.